



USER INSTRUCTIONS

RODINOR 352

RHODIUM PEN PLATING SOLUTION READY TO USE

Colour : **White**

Use : **Pen**

Colour coordinates : **L*:90.2**

a*:0.9

b*:2.0

Product description

RODINOR 352 is a white rhodium plating for pen with incomparable technical and qualitative characteristics. The properties of the deposit make this plating bath a point of reference for all goldsmiths looking for of unparalleled white and brilliant finishing for their jewellery items.

Operating conditions

Parameter	Average suggested value
Deposition time	5 - 10 seconds
Temperature	Room temperature
Voltage	10 V for brown tips - 10 V for white tips - 4 V for white buffer

Maintenance of plating bath

RODINOR 352 is to be used until exhausted.

Safety Information

Please refer to the safety data sheets for any information regarding safety and disposal (MSDS).



USER INSTRUCTIONS

RODINOR 352

RHODIUM PEN PLATING SOLUTION READY TO USE

Colour : **White**

Use : **Pen**

Colour coordinates : **L*:90.2**

a*:0.9

b*:2.0

Products related

Cod.Articles	Description	Colour	Packaging
RH030704	RODINOR 352 rhodium for pen plating ready to use	White	—